

Barco ClickShare Button GEN 4(R9861600D01C)

Barco ClickShare Button GEN 4 - Button switch



The ClickShare Conferencing Button instantly gives you access to wireless conferencing, a more immersive, interactive and guest-friendly meeting experience. Set up your remote meeting with your preferred UC solution. Plug in the USB-C device in your laptop, click and in less than 7 seconds, you are automatically connected to meeting room cameras, microphones, soundbars and any other AV peripherals. You get richer audio, have wider views of the room and can add video to your mix.

Join your next Microsoft Teams call with just one click. With either the ClickShare Button or Desktop App, you decide which suits you best. Instantly you connect wirelessly to the camera and speakers in the room for better hybrid meetings. The same is true for your Zoom, Webex or other calls as well.

Wireless conferencing with the ClickShare Button is guest-friendly, anyone can start a video call and instantly share content in any meeting room. No installation or training needed. Just plug in and go!

With the additional Quick Button you can bring the big screen back to your device, a feature called 'local view'. The Quick Button also activates advanced power functionalities like ideation, moderation, snapshots, control of AV equipment...

Alternatively, you can wirelessly conference and share content with the ClickShare Desktop App with additional functionalities for workflow integration at your disposal: pause, window selection, extended desktop, ideation and moderation. ClickShare Conference matches your digital workplace strategy. Touch or touchless, Button or App. It's your way of working, your decision.

Key Selling Points

- Iconic ClickShare component
- USB-C device to start wireless conferencing and content sharing
- Additional Quick Button with collaboration features
- Ultra-fast setup

Main Specifications

Product Description	Barco ClickShare Button GEN 4 - button switch
Product Type	Button switch

Extended Specification

General

Product Type	Button switch
--------------	---------------

*TD SYNEX is not responsible for errors in the documentation of products.